




Keurig K40 Bottom Water Filter Replacement

This guide will be used to demonstrate how to remove and replace the bottom feed water filter on a Keurig K40.

Written By: jonathan



INTRODUCTION

This guide will show an individual how to replace the water filter in the Keurig K40. This will require access to a screwdriver.



TOOLS:



- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Bottom Water Filter




- Flip the device on its side so that the metal faces you.
- Begin by unscrewing the five 1.5mm bottom screws with a #0 phillips head screwdriver.

Step 2




- Once the base is unscrewed, remove the base from the plastic wedges used to hold it in place.
- ⓘ The wires do not need to be cut as this repair will not harm or use them.

Step 3



- Using a size 0 Philips head screwdriver, remove two 1.2mm screws that hold the filter in place.
- Pull the pump back to remove it from the slot it was in.

Step 4



- Grip where the filter and the flow line connect and pull apart until they are separated.
- Clean or obtain a new filter and put back together. This is done by repeating the steps in reverse, putting the device back together.

To reassemble your device, follow these instructions in reverse order.

